

10-19-94

MP1 CLASSIC ADDITIONAL NOTATIONS TO  
STUFFING CHARTS -

- ON MAIN PCB, CAPACITOR C-39 (NEAR V-1)  
SHOULD BE STUFFED BENT OVER SO TUBE  
DONT WANT BREAK IT OFF DURING TUBE  
REPLACEMENT.

- USE RTV GLUE ON C-10, C-37, C-38.
- USE RTV GLUE ON Q-3 TO PREVENT HEATSINK FROM  
STARTING TO COVER OR HEATSINK.

- Also add one cable tie to tie the  
shielded cable, the 5 pot wires, and  
the GND #18 ga wires together.

