



NOTES

1. INSULATE ALL SHIELD DRAIN WIRES WITH HEATSHRINK TUBING.
2. APPLY HEATSHRINK TUBING TO POT BOARD ENDS OF ALL SHIELDED CABLES TO PREVENT UNRAVELING AND SHORT CIRCUITS.

DWG. # A712C 12/2/91
 ADA SIGNAL PROCESSORS
 MICROTUBE 200
 POT & JACK BOARD WIRES
 REVISED 1/6/92